

## MAYAH Communications

### Application Note 42

### ISDN Layer/Device Check

#### ISDN CAPI Layer/Device Check:

For activating the testing mode, the file **d:\isdntest.run** has to exist. This file will once be analysed during the start of the MAYAH Codec and deleted afterwards.

For disabling the testing mode the Centauri has to be rebooted.

While the testing mode is enabled, the ISDN-channels are not identified by the MAYAH codec. That means: The number of available ISDN-channels is 0.

The content of the file describes following testing possibilities:

CODE	DESCRIPTION
0	Don't send test patterns
1	Line interface passive
2	Send single Pulses 2kHz
3	Send continuous Pulses 96kHz
4	D- and B-channel reflection